



2. 接點電壓

Contact size	Test current A	Potential drop max.mV	Contact resistance max.mΩ
16	13	49	6
12	23	42	3
8	46	26	1
4	80	23	0.5
0	150	21	0.2

3. 接點規格

Shell Size	Insert Number	Contacts							Shell Size	Insert Number	Contacts						
		Tot	20	16	12	8	4	0			Tot	20	16	12	8	4	0
10SL	10SL-3	3		3					18	18-10	4			4			
	10SL-4	2		2						18-11	5			5			
12s	12s-3	2		2						18-12	6		6				
	12s-4	1		1						18-19	10		10				
	12SA10	4		4						18-20	5		5				
12	12-5	1			1					18-21	3			3			
14s	14s-1	3		3						18-22	3		3				
	14s-2	4		4				20		20-2	1						1
	14s-4	1		1						20-3	3			3			
	14s-5	5		5						20-4	4			4			
	14s-6	6		6					20-7	8		8					
	14s-7	3		3					20-11	13		13					
	14s-9	2		2					20-15	7			7				
	14SA7	7		7					20-16	9		7	2				
	14SA10	10	10						20-17	6		1	5				
14	14-3	1				1			20-18	9		6	3				
16s	16s-1	7		7						20-19	3				3		
	16s-4	2		2					20-22	6		3		3			
	16s-5	3		3					20-23	2			2				
	16s-8	5		5					20-24	4		2	2				
	16s-01	8	8						20-27	14		14					
16	16-9	4		2	2				20-29	17		17					
	16-10	3			3				20-33	11		11					
	16-11	2			2				20-01	10		10					
18	18-1	10		10					20A24	24	24						
	18-3	2			2				20A48	19		19					
	18-4	4		4				22	22-1	2				2			
	18-5	3		1	2				22-2	3				3			
	18-8	8		7	1				22-5	6		4	2				
	18-9	7		5	2				22-7	1						1	